Enterasys Vertical Horizon Suite



Supports Management Module SM-ENT1004

APRISMA SPECTRUM® POWERED SOLUTIONS

Device Management

Copyright Notice

Document 9035082-01. Copyright © September 2001 Aprisma Management Technologies, Inc., 121 Technology Drive, Durham, NH 03824 USA. All rights reserved worldwide. Use, duplication, or disclosure by the United States government is subject to the restrictions set forth in DFARS 252.227-7013(c)(1)(ii) and FAR 52.227-19.

Liability Disclaimer

Aprisma Management Technologies, Inc. (“Aprisma”) reserves the right to make changes in specifications and other information contained in this document without prior notice. In all cases, the reader should contact Aprisma to inquire if any changes have been made.

The hardware, firmware, or software described in this manual is subject to change without notice.

IN NO EVENT SHALL APRISMA, ITS EMPLOYEES, OFFICERS, DIRECTORS, AGENTS, OR AFFILIATES BE LIABLE FOR ANY INCIDENTAL, INDIRECT, SPECIAL, OR CONSEQUENTIAL DAMAGES WHATSOEVER (INCLUDING BUT NOT LIMITED TO LOST PROFITS) ARISING OUT OF OR RELATED TO THIS MANUAL OR THE INFORMATION CONTAINED IN IT, EVEN IF APRISMA HAS BEEN ADVISED OF, HAS KNOWN, OR SHOULD HAVE KNOWN, THE POSSIBILITY OF SUCH DAMAGES.

Trademark, Service Mark, and Logo Information

SPECTRUM, **IMT**, and the **SPECTRUM IMT/VNM** logo are registered trademarks of Aprisma Management Technologies, Inc., or its affiliates. **APRISMA**, **APRISMA MANAGEMENT TECHNOLOGIES**, the **APRISMA MANAGEMENT TECHNOLOGIES** logo, **MANAGE WHAT MATTERS**, **DCM**, **VNM**, **SpectroGRAPH**, **SpectroSERVER**, **Inductive Modeling Technology**, **Device Communications Manager**, **SPECTRUM Security Manager**, and **Virtual Network Machine** are unregistered trademarks of Aprisma Management Technologies, Inc., or its affiliates. For a complete list of Aprisma trademarks, service marks, and trade names, go to http://www.aprisma.com/manuals/trademark-list.htm.

All referenced trademarks, service marks, and trade names identified in this document, whether registered or unregistered, are the intellectual property of their respective owners. No rights are granted by Aprisma Management Technologies, Inc., to use such marks, whether by implication, estoppel, or otherwise. If you have comments or concerns about trademark or copyright references, please send an e-mail to spectrum-docs@aprisma.com; we will do our best to help.

Restricted Rights Notice

(Applicable to licenses to the United States government only.)

This software and/or user documentation is/are provided with RESTRICTED AND LIMITED RIGHTS. Use, duplication, or disclosure by the government is subject to restrictions as set forth in FAR 52.227-14 (June 1987) Alternate III (g)(3) (June 1987), FAR 52.227-19 (June 1987), or DFARS 52.227-7013 (c)(1)(ii) (June 1988), and/or in similar or successor clauses in the FAR or DFARS, or in the DOD or NASA FAR Supplement, as applicable. Contractor/manufacturer is Aprisma Management Technologies, Inc., 121 Technology Drive, Durham, NH 03824. In the event the government seeks to obtain the software pursuant to standard commercial practice, this software agreement, instead of the noted regulatory clauses, shall control the terms of the government's license.

Virus Disclaimer

Aprisma makes no representations or warranties to the effect that the licensed software is virus-free.

Aprisma has tested its software with current virus-checking technologies. However, because no anti-virus system is 100 percent effective, we strongly recommend that you write-protect the licensed software and verify (with an anti-virus system in which you have confidence) that the licensed software, prior to installation, is virus-free.

Contact Information

Aprisma Management Technologies, Inc.
121 Technology Drive
Durham, NH 03824

Phone:	603.334.2100
U.S. toll-free:	877.468.1448
Web site:	http://www.aprisma.com

Contents

INTRODUCTION 4

Purpose and Scope 4
Required Reading 4
Supported Devices 5
VH-4802 5
VH-2402S/ELS100-S24TX2M 5
VH-8G 5
VH-8TX1UM 5
The SPECTRUM Model 6

TASKS 8

DEVICE VIEW 9

Interface Icons 10
Interface Icon Subviews Menu 11
Interface Status View 12
Secondary Address Panel 12

DEVICE TOPOLOGY VIEW 13

APPLICATION VIEWS 14

Main Application View 14
Supported Applications 15
Common Applications 15
Device-Specific Applications 16
ELS100-24 Application (ELS100_TxApp) 16
System Information View 17
Switch Manager View 18
Port Table Information View 18
VLAN Table Information View 19
Port Mirror Configuration View 20
VLAN Port Table Information View 21
Port Priority Table Information View 21

PERFORMANCE VIEWS 22

Device Performance View 23
Port Performance View 23

CONFIGURATION VIEWS 24

Device Configuration View 24
Interface Configuration View 25
Generic Interface Trap Configuration View 25

MODEL INFORMATION VIEW 26

INDEX 27

Introduction

This section introduces the SPECTRUM Device Management documentation for the Vertical Horizon series of switches manufactured by Enterasys.

This introduction contains the following topics:

- *Purpose and Scope*
- *Required Reading*
- *Supported Devices* (Page 5)
- *The SPECTRUM Model* (Page 6)

Purpose and Scope

Use this document as a guide for managing the Enterasys devices described on Page 5 with SPECTRUM management module SM-ENT1004. This document describes the icons, menus, and views that enable you to remotely monitor, configure, and troubleshoot Enterasys devices through software models in your SPECTRUM database.

Information specific to SM-ENT1004 is what is primarily included in this document. For general information about device management using SPECTRUM and explanations of SPECTRUM functionality and navigation techniques, refer to the topics listed under *Required Reading*.

Required Reading

To use this documentation effectively, you must be familiar with the information covered by the other SPECTRUM online documents listed below.

- ***Getting Started with SPECTRUM for Operators***
- ***Getting Started with SPECTRUM for Administrators***
- ***How to Manage Your Network with SPECTRUM***
- ***SPECTRUM Views***
- ***SPECTRUM Menus***
- ***SPECTRUM Icons***
- ***SPECTRUM Software Release Notice***

Supported Devices

SPECTRUM management module SM-ENT1004 currently lets you model the Enterasys Vertical Horizon (formerly SmartSTACK) suite of switches. These are high performance switches that offer high-speed uplinks, RMON support, port trunking and port monitoring. There are four different models of the Vertical Horizon switches, as described below.

VH-4802

The Vertical Horizon VH-4802 provides 48 RJ45 ports of wire-speed 10/100Base-TX connectivity and two option slots for modular 100Base-FX and 1000Base-X uplinks.

VH-2402S/ELS100-S24TX2M

The Vertical Horizon VH-2402S provides 24 10/100 Mbps RJ45 ports and two option slots for expansion, as well as a dedicated management slot. The ELS100-S24TX2M is a pre-Vertical Horizon version of the VH-2402S device.

VH-8G

The Vertical Horizon VH-8G is an 8 port Gigabit Ethernet standalone workgroup switch suitable for supporting network-intensive applications and high-volume file transfers.

VH-8TX1UM

The Vertical Horizon VH-8TX1UM is an 8 port, 10/100 Mbps wire-speed switch.

The SPECTRUM Model

The model type for the Vertical Horizon devices is VH_Switch. The Device Type shown on the modeled device's device icon will reflect the actual device being modeled, as shown in Figure 1.

Modeling results in the creation of Device icons that represent the devices and Application icons that represent their supported applications.

The Device icons contain double-click zones and provide access to Icon Subviews menus that let you perform device management activities such as those listed in *Tasks* on Page 8.

As Figure 1 shows, the appearance of the Device icons varies slightly depending on the kind of view it appears in.

Figure 1: Device Icons


Model Name
VH_2402S
Small Device icon appears in Topology and Application views
Large Device icon appears in Device Topology, Location, and Device Interface views.
Model Name
VH_2402S

The device-specific Icon Subviews menu options available from the Device icon are listed below.

Option	Accesses the...
Device	*Device View* (Page 9)
Device Topology	*Device Topology View* (Page 13)
Application	*Application Views* (Page 14)
Configuration	*Configuration Views* (Page 24)
Model Information	*Model Information View* (Page 26)
Primary Application	Menu options that let you select either Routing, IP Routing, Gen Bridge App, MIB-II or an Ethernet App as the primary application.

The rest of this document covering the Enterasys Vertical Horizon Suite management module is organized as follows.

- *Tasks* (Page 8)
- *Device View* (Page 9)
- *Device Topology View* (Page 13)
- *Application Views* (Page 14)
- *Performance Views* (Page 22)
- *Configuration Views* (Page 24)
- *Model Information View* (Page 26)

Tasks

This section contains an alphabetical list of device management tasks, with each task providing one or more links to views that let you perform the task.

Administrative Information (check)

- *Model Information View* (Page 26)

Alarm Thresholds (set)

- *Interface Icon Subviews Menu* (Page 11)

Configuration Information (check)

- *Configuration Views* (Page 24)

IP Address (find/change)

- *Device View* (Page 9)
- *Secondary Address Panel* (Page 12)

Network Type (check)

- *Network Type Label* (Page 11)

Performance (check)

- *Device View* (Page 9)
- *Interface Icons* (Page 10)
- *Performance Views* (Page 22)

Port Status (check/change)

- *Interface Status View* (Page 12)

Topology (check)

- *Device Topology View* (Page 13)

Device View

This section describes the Device view and subviews available for models of Enterasys Vertical Horizon devices in SPECTRUM.

Access: *From the* ***Icon Subviews*** *menu for the Device icon, select* ***Device > Interface****.*

This view (Figure 2) uses icons and labels to represent the device and its components, such as modules, ports, and applications. The view provides dynamic configuration and performance information for each of the device's serial and network I/O ports, which are represented by Interface icons in the bottom panel of the view. The middle panel of the view displays a Device icon, which lets you monitor the device operation and access other device-specific views.

Figure 2: Device View



Interface Icons

Figure 3 shows a close-up of an Interface icon from the Device view. Most of the informational labels on the icon also provide double-click access to other views, as explained in the following label descriptions.

Figure 3: Interface Icon



a *Interface Number Label*

b *IF Status Label*

c *Interface Type Label*

d *Network Type Label*

e *Physical Address Label*

f *IP Address Label*

Interface Number Label

This label displays the interface (port) number.

IF Status Label

This label displays the current status of the interface for the primary application selected, e.g., Gen Rtr App or MIB-II App. Table 1 lists the possible label color representations. Note that the color of the label also depends on the interface's current Administrative Status, which you set in the *Interface Status View* (Page 12). This view can be accessed by double-clicking the label.

Table 1: Interface Status Label Colors

Color	Operational Status	Administrative Status	Label Text
Green	up	up	ON
Blue	down	down	OFF
Yellow	down	up	OFF
Red	testing	testing	TEST

Interface Type Label

This label identifies the interface type (Ethernet, ATM, etc.). Double-click this label to access the *Interface Configuration View* (Page 25).

Network Type Label
This label identifies the type of network to which the interface is connected. Double-click the label to open the Model Information view for the interface.

Physical Address Label
This label displays the physical (MAC) address of the interface. Double-click this label to open the IF Address Translation Table.

IP Address Label
This label displays the IP address for the interface. Double-click this label to open the *Secondary Address Panel* (Page 12), which lets you change the address and mask for the interface.

Interface Icon Subviews Menu

Table 2 lists the device-specific interface Icon Subviews menu options and the views to which they provide access.

Table 2: Interface Icon Subviews Menu

Option	Accesses the...
Detail	Interface Detail view, which displays packet, error, and discard breakdown statistics for the interface.
IF Status	*Interface Status View* (Page 12).
IF Configuration	*Interface Configuration View* (Page 25).
IF Address Translation Table	Interface Address Translation Table, which identifies the physical and network address for the interface.
Secondary Address Panel	*Secondary Address Panel* (Page 12).
Thresholds	Interface Threshold view, which lets you set the on/off alarm thresholds for load, packet rate, error rate, and % discarded for the interface.
Model Information	*Model Information View* (Page 26).

Interface Status View

Access: *From the **Icon Subviews** menu for the Interface icon in the Device view, select **IF Status**.*

This view provides information on the operational status of the interface and allows you to enable or disable the port.

Operational Status
The current state of the interface (`Up`, `Down`, `Unknown`, `Dormant`, `Not Present`, `Lower Layer Down`, or `Testing`).

Administrative Status

This button allows you to select the desired administrative state of the interface (`On`, `Off`, or `Testing`).

Secondary Address Panel

Access: *From the **Icon Subviews** menu for the Interface icon in the Device view, select **Secondary Address Panel**.*

This panel provides a table of IP addresses and masks obtained from the Address Translation table within the device's firmware. You can change the current address displayed in the **IP Address** field by selecting an entry from the table in this panel and clicking the **Update** button.

Device Topology View

This section describes the Device Topology view available for models of the Enterasys Vertical Horizon devices.

Access: *From the* ***Icon Subviews*** *menu for the Device icon, select* ***Device Topology****.*

The Device Topology view (Figure 4) shows the connections between a modeled device and other network entities. The lower panel of the view uses Interface icons to represent the device's serial, network, and I/O ports. These icons provide the same information and menu options as those in the *Device View* (Page 9). If a device is connected to a particular interface, a Device icon appears on the vertical bar above the Interface icon along with an icon representing the network group that contains the device.

Refer to the ***SPECTRUM Views*** documentation for details on Device Topology view.

Figure 4: Device Topology View



Application Views

This section describes the main Application view and the associated application-specific subviews available for models of Enterasys Vertical Horizon devices in SPECTRUM.

Access: *From the* ***Icon Subviews*** *menu for the Device icon, select* ***Application****.*

Main Application View

When a device model is created, SPECTRUM automatically creates models for each of the major and minor applications supported by the device. The main Application view identifies all of these application models, shows their current condition status, and provides access to application-specific subviews. Figure 5 shows this view in the Icon mode. If you prefer the List mode, which displays applications as text labels, select **View > Mode > List**.

For more information on this view, refer to the ***MIBs and the Application View*** documentation.

Figure 5: Main Application View



Supported Applications

SPECTRUM's applications can be grouped within two general categories as follows:

- *Common Applications*, below
- *Device-Specific Applications* (Page 16)

Common Applications

For the most part, these applications represent the non proprietary MIBs supported by your device. Listed below (beneath the title of the document that describes them) are some of the common applications currently supported by SPECTRUM.

Note: The documents listed are available for viewing at: www.aprisma.com/manuals/

- ***Routing Applications***
  - Generic Routing
  - Repeater
  - AppleTalk
  - DECnet
  - OSPF
  - OSPF2
  - BGP4
  - VRRP
- ***Bridging Applications***
  - Ethernet Special Database
  - Spanning Tree
  - Static
  - Transparent
  - PPP Bridging
  - Source Routing
  - Translation
  - QBridge
- ***MIB II Applications***
  - SNMP
  - IP
  - ICMP
  - TCP
  - System2
  - UDP
- ***Transmission Applications***
  - FDDI
  - Point to Point
  - DS1
  - DS3
  - RS-232
  - WAN
  - Frame Relay

- Token Ring
- Ethernet
- Fast Ethernet
- rfc1317App
- rfc1285App
- rfc1315App
- 802.11App
- SONET

- ***Technology Applications***
  - APPN
  - ATM Client
  - DHCP
  - PNNI
  - rfc1316App
  - DLSw

Device-Specific Applications

The Enterasys Vertical Horizon devices do not currently support any device-specific applications. The ELS100-24TX series of devices support a single device-specific application, **ELS100_TxApp**, described in the rest of this section.

ELS100-24 Application (ELS100_TxApp)

This application has the following application-specific subviews:

- *System Information View* (Page 17)
- *Switch Manager View* (Page 18)
- *Port Table Information View* (Page 18)
- *VLAN Table Information View* (Page 19)
- *Port Mirror Configuration View* (Page 20)
- *VLAN Port Table Information View* (Page 21)
- *Port Priority Table Information View* (Page 21)

System Information View

Access: *From the **Icon Subviews** menu for the Application icon, select **System Information.***

This view provides system-level configuration information.

Sys Serial no
The serial number of the system.

Tftp IP Address
The IP address of the TFTP server from which a software download is to be initiated. This variable must be set before a TFTP download can be started.

Tftp Filename
The name of the software upgrade file residing on the TFTP server. Path information must be included in the file name. This variable must be set before a TFTP download can be started.

Brcast Cutoff Rate
The Broadcast Cutoff Rate of the switch controlling broadcast storms. The value of this variable sets a per second rate. If the broadcast and unknown destination address frames being forwarded through the system surpass this rate, they are dropped. Valid values for this parameter are in the range (100 to 500000).

Switch IP Address
The IP address of the ELS device.

Switch Subnet Mask
The subnet mask associated with the IP address of the system.

Gateway IP Address
The IP address of the next hop router (gateway) to which frames destined for an IP subnet are sent.

Tftp Start Download
Start a TFTP download. A SET of this variable with the value download initiates a TFTP download to upgrade the system software. The variables TFTP IP Address and TFTP Filename must be configured before a download can begin. A GET of this variable will always return the value noDownload.

BootP Dhcp Enabled
Enable or disable the operation of the BootP and DHCP protocols on the system. These protocols are used for automatically configuring the system's IP address information if a properly configured BootP and/or DHCP server exists on the network.

System Reset
Initiates a software reset of the system. Values are Reset or noReset.

Powerup Count
The total number of times the system has powered up since manufacture.

Switch Manager View

Access: *From the **Icon Subviews** menu for the Application icon, select **Switch Manager.***

This view provides trap information for the four SNMP managers on this system.

Trap Rcvr (#1,2,3,4)
The IP address for each of the four SNMP managers to which traps are sent.

Trap Community (#1,2,3,4)
The community name for each of the four SNMP managers to which traps are sent. The default value is public.

Port Table Information View

Access: *From the **Icon Subviews** menu for the Application icon, select **Port Information.***

This view shows a table with traffic information for each of the ports on the system.

Port
The number of the port, from 1 to the number of ports on the system.

Port Status
The connection, or link, status of the port, either up (linked) or down (not linked).

Duplex Status
The duplex status of the port. The values are `half` or `full duplex`.

Forwarded Frames
The number of frames received on this port and forwarded to another port on the system module.

Rcvd Local Frames
The number of frames received on this port.

Port Name
A descriptive string of up to 60 characters used by the network administrator to name the port.

Port Enable
Status of the port; values are `Enable` or `Disable`.

Port Speed
The operating speed for this port. Values are: `ten Mbps` or `one hundred Mbps`.

Autoneg Enable
The auto-negotiation status of the port (`Enable` or `Disable`). When enabled, the port automatically configures its duplex and speed operation.

Flow Control Enable
The state of flow control operation for this port. Flow Control allows you to manage network traffic during congestion periods and to prevent loss of packets when the port buffer thresholds are exceeded. Values are `Enable` or `Disable`.

Port Type
The port physical interface types are, listed below.

ieee100BaseTx
ieee100BaseFx-MMF
ieee100BaseFx-SMF
ieee1000BaseCx
ieee1000BaseLx
ieee1000BaseSx
ieee1000BaseT

ElsInOctets
Incoming traffic on this port, measured in octets.

VLAN Table Information View

Access: *From the **Icon Subviews** menu for the Application icon, select **VLAN Information.***

The VLAN Table Information view shows the VLAN table, which is indexed by VLANs.

Vlan Id
The number of the VLAN, from 1 to the number of VLANs supported on the system.

Vlan Name
A descriptive string of up to 60 characters used by the network administrator to name the VLAN.

Vlan Ports
The set of ports in the VLAN. For systems supporting tagged VLAN's, these are the ports to which packets on the VLAN are sent untagged.

Vlan Egress Ports
The set of ports on other VLANs, to which tagged packets destined for this specific VLAN should also be sent.

Vlan Status
Control variable used to enable or disable the operation of the associated VLAN in the system.

Switch Vlan Enable
Globally `Enable` or `Disable` the VLAN operation of the system.

Switch STP Status
Enables or disables the mirroring of transmitted traffic out the mirrored port to the mirroring port. Values are `On or Off`.

Port Mirror Configuration View

Access: *From the **Icon Subviews** menu for the Application icon, select **Port Mirror Configuration.***

This view allows you to configure one port to monitor, or mirror, traffic on another active port. You can only "watch" this traffic from the mirroring port.

Rcv Mirror Enable
Enable or disable the mirroring of received traffic. Once this field is enabled, you can monitor mirrored port traffic on the mirroring port.

Mirroring Port
The selected port that is mirroring another port.

Xmit Mirror Enable
`Enable` or `Disable` the mirroring of transmitted traffic out the mirrored port to the mirroring port.

Port Mirroring Status
The Port Mirroring status of the system. Values are `Enable` or `Disable`.

Mirrored Port
The port, or source, that is being mirrored.

VLAN Port Table Information View

Access: *From the **Icon Subviews** menu for the Application icon, select **VLAN Port Information.***

Vlan PortId

The VLAN port number, from 1 to the number of ports in the system.

Vlan Pvid

The port's VLAN ID. For tagged VLANs, this variable defines a 12 bit port VLAN ID (PVID) used as the identifier of the VLAN in the packet tag.

Vlan Port Type

For tagged VLANs or VLAN port type, either `hybrid` or `access`. Hybrid ports allow both tagged and untagged packets to enter the switch. Access ports only accept untagged packets.

Port Priority Table Information View

Access: *From the **Icon Subviews** menu for the Application icon, select **Port Priority Information.***

This view contains a table that shows priority level (0 to 7) each port assigns to untagged traffic.

Performance Views

This section provides brief descriptions of the Performance views available for the Enterasys Vertical Horizon devices in SPECTRUM.

Performance views display performance statistics in terms of a set of transmission attributes, e.g., cell rates, frame rates, % error, etc. A typical view is shown in Figure 6. The instantaneous condition of each transmission attribute is recorded in a graph. The statistical information for each attribute is presented in the adjacent table.

Generally, you determine performance at the device level through Performance views accessed from the Device and Application icons. You determine performance at the port/interface level through Performance views accessed from Interface icons.

For more information on Performance views, refer to the ***SPECTRUM Views*** documentation.

The following paragraphs list the performance attributes displayed for each Performance view supported by this management module.

Figure 6: Performance View



Device Performance View

Access: *From the **Icon Subviews** menu for the Device icon, select **Performance**.*

Current and historical frame transmission information is provided via the following attributes.

- Frame Rate
- % Delivered
- % Forwarded
- % Transmit
- % Error
- % Discarded

Port Performance View

Access: *From the **Icon Subviews** menu for the Device Interface icon, select **Performance**.*

Current and historical packet transmission information is provided via the following attributes.

- Load
- Packet Rate
- % Error
- % Discarded

Configuration Views

This section describes the various Configuration views available for models of the Enterasys Vertical Horizon devices in SPECTRUM.

Configuration views let you view and modify current settings for the modeled device and its interfaces, ports, and applications. The following Configuration views are available for models of Enterasys Vertical Horizon devices:

- *Device Configuration View* (Page 24)
- *Interface Configuration View* (Page 25)
- *Generic Interface Trap Configuration View* (Page 25)

Device Configuration View

Access: *From the* ***Icon Subviews*** *menu for the Device icon, select* ***Configuration****.*

This view (Figure 7) provides status and configuration information about the device as a whole as well as on a port-by-port basis. Fields and column headings within the Device Configuration view and its subviews are explained in detail in the ***SPECTRUM Views*** documentation.

Figure 7: Device Configuration View



Interface Configuration View

Access: *From the **Icon Subviews** menu for an Interface icon in the Device view, select **IF Configuration**.*

This view provides the following information for the selected interface:

Index
Indicatates which device is being examined.

Operation Status
The current operational state of the interface (`Up`, `Down`, `Unknown`, `Dormant`, `Not Present`, or `Lower Layer Down`).

Admin. Status

The desired operational state of the interface (`up`, `down`, or `testing`).

Last Change
The System UpTime value when the interface entered its current operational state.

IP Address/Network Mask
This window provides a list of the user-defined names and IP addresses for the interface.

Physical Address
The Ethernet (MAC) address of the interface.

Bandwidth
The estimated bandwidth of the interface, measured in bits per second. For interfaces that do not vary in bandwidth, or no accurate estimate can be made, a nominal bandwidth is provided.

Packet Size
The largest packet that can be transmitted or received by the port, displayed in octets.

Queue Length
The length of the outbound packet queue, in packets.

Generic Interface Trap Configuration View

Access: *From the **Icon Subviews** menu for an Interface icon in the Device view, select **Model Information.** In the Model Information view, click the **Trap Configuration** button to access the Generic Interface Trap Configuration view.*

This view allows you to enable or disable trap events and set alarms on Link down traps. Click **Button Explanations** for more information.

Model Information View

This section provides a brief overview of the Model Information view.

This view displays administrative information about the device and its applications and lets you set thresholds and alarm severity for the device.

Figure 8 shows a sample Model Information view. The layout of this view is the same for all model types in SPECTRUM but some information will vary depending on the model it defines. Refer to the ***SPECTRUM Views*** documentation for a complete description of this view.

Figure 8: Model Information View



Index

A

Address
  Interface IP 11
  Physical (MAC) 11
  Translation 12
Admin Status 10, 25
Applications 14
Autoneg Enable 18

B

Bandwidth 25
BootP 17
BootP Dhcp Enabled 17
Brcast Cutoff Rate 17
Button Explanations 25

C

Configuration
  Device 24
  Interface 25

D

DevTop Views 13
DHCP protocol 17
Disable the mirroring 20
Documentation 4
Duplex Status 18

E

ElsInOctets 19
Enable mirrored received traffic 20

F

Flow Control 19

H

Hardware 5
Hybrid or access 21
Hybrid ports 21

I

Icons
  Device 6
  Interface 10
Interface
  Status 12
  Type, Device 10
IP Address/Network Mask 25

L

Last Change 25

M

Management Tasks 8
Mask 12
Mirrored Port 20
Model
  Information 26
  Types of 6

Index

N

Network I/O ports 13
Network Type 11

O

Operation Status 25

P

Packet Size 25
Performance Statistics 22
Physical Address 25
Port Mirroring Status 20
Port Number, Device 10
Powerup Count 18
Priority Port Id 21
PVID 21

Q

Queue Length 25

R

Rcv Mirror Enable 20
Rcvd Local Frames 18

S

Serial ports 13
Statistics
  Routing Frame Transmission 23
Switch Manager 16
Switch STP Status 19
Switch Subnet Mask 17
Switch Vlan Enable 19
Sys Serial no 17
System Reset 17

T

Tftp Filename 17
Tftp IP Address 17
TFTP server 17
Tftp Start Download 17
Threshold Information 11
Trap Community 18
Trap Rcvr 18
Troubleshooting 8

U

Untagged packets 21

V

Vlan Egress Ports 19
Vlan Id 19
Vlan Name 19
Vlan Port Type 21
Vlan PortId 21
Vlan Ports 19
Vlan Pvid 21
Vlan Status 19

X

Xmit Mirror Enable 20